



# Driver's Guide to Data Transfer at Roadside Checks

**! IMPORTANT:** This document must be kept in the Commercial Motor Vehicle (CMV) at all times, and made available during a roadside check in accordance to §395.22 (h). The Drive App supports the telematics transfer, which electronically transfers data to an authorized safety officer on demand via wireless Web Services and Email (Option 1). For more details, see 49 CFR Part 395, Appendix to Subpart B – Electronic Logging Devices (Section 4.9.1).

**! IMPORTANT:** In order to improve our products, we may at any time, and without warning, change the design, presentation, or functionality of the software.



Roadside Check is at the bottom left of the main dashboard




Optional PIN dialog that appears when starting a Roadside Check


## Roadside Checks

In the event of a roadside check:


1. From the Dashboard, press **Roadside Check**.
2. (Optional) For your privacy, you can choose to specify a 4-digit PIN that is required to exit Roadside Check mode. Either enter a PIN and press **Set PIN**, or press **No PIN** to proceed without one.
3. The next part of the workflow differs slightly based on your current location (USA or Canada). Do one of the following:
  - a. To transfer HOS logs, enter the **Transfer Code** or **Email Address** provided by the officer, and then press either **Email** or **Web services** for drivers in the US, or **Transfer (Canada)** for drivers in Canada.
  - b. If these transfer services fail (such as in areas with poor cell coverage), press **Compliance print** to display the report on your mobile device. The officer can use the arrows to move between days, and scroll through each report to display all information for that day.
4. To review previous asset inspections, press the **Asset Inspection** tab at the top of the screen and then press **View**. To see the list of defects used in each inspection, scroll down and press **View**.
5. To exit the **Asset Inspection** view, close the defects list and then press the arrow at the top left of the screen.
6. To exit **Roadside Check**, press **Exit** at the top right and then enter the PIN (if one was specified).



Sample transfer screen for a driver in the USA



Sample transfer screen for a driver in Canada



Press **Exit** at the top right to return to the Dashboard